

Jeep Wrangler JK (2007-2017) Aluminum Front Inner Fenders

Contents:

- (1) Left Inner Fender
- (1) Right Inner Fender
- (2) "L" Brackets
- (12) M6x1.0 Allen Head Bolts
- (12) M6 Lock Washers
- (12) M6 Flat Washers
- (6) Clip Nuts
- (1) Allen Wrench

Tools Required:

- Socket Set
- Drill
- Drill Bit
- Marker
- Tin Snips/ Cutting Tool



1 Locate the mounting locations on the fender well.



2 Remove the factory 10mm bolt and loosely install the supplied "L" bracket. Then slide on the supplied clip nut.



3 Loosely install the inner fender liner using the supplied Allen bolts. Using a marker, mark the hole locations on the rear most holes. These will need to be drilled. Remove the fender liners. Tighten the factory 10mm nut now that the bracket is in the correct location.



4 Drill a 1/8" pilot hole and then drill the holes to 3/8". Install the supplied clip nuts. **Note: It may be necessary to trim the inner fender lip in order to slide the clip nut on.



5 Install fender liners using the supplied bolts, lock washers, and large washers.



Jeep Wrangler JK (2007-2017) Fender Inners - Rear

Contents:

- (1) Left Inner Fender
- (1) Right Inner Fender
- (4) M6x1.0 Allen Head Bolts
- (4) M6 Flat Washers (Large)
- (12) M6 Flat Washers (Small)
- (4) Lock Nuts
- (8) Phillips Screws
- (1) Allen Wrench

Tools Required:

- Socket Set
- Drill
- Drill Bit
- Marker

J107328



1
Locate the factory mounting locations on fender well.



3
Mark the remaining holes for drilling. Drill a pilot hole using a 1/8" drill bit. Then drill a 5/32" hole.



2
Secure the rear fender liners using the supplied Allen bolts. **Note: The large washer goes on the tire side of the liner. The small washer goes on the chassis side of the washer.



4
Install the supplied screws/small washers into the remaining holes.