



**PRODUCT: 8897RSB**  
**2007-2012 JEEP JK RUBICON REAR SWAY BAR END LINKS**

**PARTS LIST**

**QTY**

SWAY BAR END LINK	2
1/2-13x2 3/4" HEX CAP SCREW	2
1/2-13 NYLOCK NUT	2
1/2" FLAT WASHER	4

PLEASE DOUBLE CHECK THE PARTS LIST BEFORE BEGINNING INSTALLATION, TO ENSURE ALL PARTS ARE PRESENT, IF THERE IS SOMETHING MISSING, PLEASE CONTACT MAXTRAC IMMEDIATELY  
877-929-3016

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING THE INSTALLATION.

**PRIOR TO INSTALLATION:**

1. Factory service manual is recommended to have on hand.
2. Secure and properly block vehicle prior to beginning installation
3. Always wear safety glasses when using power tools or working under the vehicle
4. Modifications to any part will void the warranty associated with that product.

After removing parts from vehicle, save hardware for reinstallation

**IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING NEW SUSPENSION. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.**

## **8897RSB INSTALLATION INSTRUCTIONS**

### **2007-2012 JEEP JK RUBICON REAR SWAY BAR END LINKS**

- 1) DISCARD THE 8397FSB FRONT SWAY BAR DROP BRACKET THAT CAME WITH YOUR MAXTRAC 839725 KIT, IT WILL NOT FIT THE RUBICON MODELS WITH FRONT ELECTRONIC SWAY BAR
- 2) REMOVE BOTH FRONT AND REAR SWAY BAR END LINKS
- 3) TAKE THE FACTORY REAR SWAY BAR END LINKS, REMOVE THEM, AND RE-INSTALL BOTH LINKS TO THE FRONT SWAY BAR.
- 4) INSTALL THE MAXTRAC SWAY BAR END LINKS ON THE REAR SWAY BAR USING FACTORY HARDWARE AND THE PROVIDED HARDWARE.