

Jeep Wrangler (18+ JL) Extreme HD Adventure Doors - Front

Contents:

- | | |
|--------------------------|-------------------------|
| (1) Left Front Door | (4) M6x1.0x25mm Screws |
| (1) Right Front Door | (4) M6 Flat Washers |
| (2) JK Style Mirrors | (4) M6 Lock Washers |
| (2) Mirror Mounts | (2) M4x0.7x20mm Screws |
| (2) Latches | (6) M5 Flat Washers |
| (6) Latch Spacers | (2) Allen Wrenches |
| (2) Door Straps | |
| (2) Door Rubber Stoppers | |
| (4) M10x1.5x20mm Bolts | Tools Required: |
| (4) M10 Flat Washers | Trim Panel Removal Tool |
| (4) M10 Lock Washers | T50 Torx Bit |
| (2) M8x1.25x20mm Screws | T40 Torx Bit |
| (4) M8 Lock Nuts | Rubber Mallet |
| (6) M8 Flat Washers | 10mm Socket |
| (2) M8 Lock Washers | Ratchet |



Begin by removing the T-50 Torx nuts on the bottom of the factory door hinges. These will not be reused.



Using a panel removal tool, pry the kick panel off.



Roll down the windows so that the door is easier to handle while removing it from the vehicle. Unplug the connector. Slide the hinge strap off the chassis mount.



Locate, and remove the T40 torx bolt securing factory door hinge stop. Lift the door up to remove it from the vehicle. Then reinstall the factory T40 torx bolt as a place holder to ensure it doesn't get lost.



Install the new door, you may need to use a rubber mallet to seat the door all the way onto the hinge. Use the supplied M8 nut and washer to secure the door to the hinge.



6

Install the rubber door stopper to the door using the M4x0.7x15mm screw, and M4 flat washer.



7

Loosely install the door latch using the M6x1.0x25mm screws, flat washers, and lock washers.




8

Align the door latch with the striker using the latch spacers as seen above. **Note: Spending extra time aligning the latch to the striker will result in a smoother feel when opening and closing the door.



9

Install the door strap from the HD Adventure Door to the chassis mount. Reinstall the trim panel.



10

Install the mirror mount to the door using the (2) M10x1.5x20mm bolts, lock washers, and flat washers.



11

Install the supplied mirror to the mirror mount using the (1) M8x1.25x20mm screw, flat washer, and lock washer. Installation is now complete.