

ALTERUM

MULTI-FUNCTION CLIP HOLDER

(2018+ WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Clip Assembly
- (2) Replacement Clips
- (1) Soft Pry Tool

TOOLS REQUIRED

10mm Socket and Ratchet

SKU # J133783-JL

ALTERUM

STEP 1



Using the provided soft pry tool, carefully pry the HVAC control panel away from the vehicle.

STEP 2



Using a 10mm Socket and ratchet, remove the 10mm bolt that hold the left side of the dash grab handle to the vehicle.

ALTERUM

STEP 3



Gently pull the handle away from the dash and place the clip assembly between the handle and the dashboard. Re-install the 10mm bolt.

STEP 4



Ensure all the of clips are present on the HVAC panel, if any are missing replace them with the provided clips.

ALTERUM



STEP 5

Press the HVAC panel back into the dashboard. Installation is now complete.