



SPARE TIRE DELETE-VENTED

(2018+ WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Spare Tire Delete

TOOLS REQUIRED

Soft Pry Tool
Needle Nose Pliers
13mm Socket and Ratchet
Lug Wrench
T40 Torx Wrench

SKU # J133784-JL

STEP 1

Begin by opening the tailgate to gain access to the tailgate trim panel. Using a soft pry tool, pry the trim panel away from the tailgate. Any of the green clips that remain in the tailgate will need to be removed and press back onto the trim panel prior to re installation.

STEP 2

Remove the 3rd brake light and reverse camera wiring connections. Depress the tab and pull the plugs apart.

**STEP 3**

Using a T40 torx wrench unlock the reverse camera trim panel and remove it from the vehicle. Using a lug wrench, remove the (3) lug nuts securing the spare tire to the vehicle. Remove the tire.

**STEP 4**

Pull the wiring harness through the hole in the tailgate. Using a 13mm socket, remove the (8) bolts securing the factory tire carrier to the vehicle.



STEP 5

Using a soft pry tool, remove the factory tailgate vents.



STEP 6

Install the spare tire delete using the factory hardware removed in Step 5. Installation is now complete.