



HIGH CLEARANCE REAR FENDER FLARES

(2018-2020 WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Rear Flares
(2) Front Supports
(2) Rear Supports
(11) M6 Plastic Clips
(20) M8 Plastic Clips
(24) Rubber Grommets
(24) Fender Clips

TOOLS REQUIRED

Panel Removal Tool
Wire Cutters

SKU # J138355-JL

STEP 1



Remove (8) push clips in the inner fender liner.

STEP 2



Remove the (6) plastic rivets by pushing the center of the rivet in. Remove the inner fender liner from the vehicle.



STEP 3

Depress the plastic fender clips around the fender flare while pulling the fender flare away from the vehicle.



STEP 4

Install new fender flare and fender liner following steps 1-3 in reverse order .