

REAR CARGO NET DIVIDER

(2007-2018 WRANGLER JK 4 DOOR, 2018-2020 WRANGLER JL 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

TOOLS REQUIRED

- (1) Storage System
- (2) Clips

T-40 Torx Socket





STEP 1

Using the (2) top straps, attach the storage system to the top roll bar on the vehicle. Do not tighten straps.



STEP 2

Using the corner straps, attach the corners to the roll bar on the vehicle. Do not tighten these straps.





STEP 3

Remove (1) T-40 Torx bolt from each side of the vehicle. Place the provided clip onto the bolt, then refasten the bolt into the vehicle.



STEP 4

Clip the side hook straps into the previously fastened clips. Do not tighten these straps.





STEP 5

Clip the bottom hook straps into the anchor point on the base of the rear seat.



STEP 6

Tighten all storage system straps evenly.

Installation is now complete.