



# TAILGATE HINGE COVERS; CHROME

(2007-2018 WRANGLER)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(2) LARGE HINGE COVERS  
(2) SMALL HINGE COVERS

### TOOLS REQUIRED

---

N/A

## STEP 1



Clean the tailgate hinge surfaces prior to installation using alcohol wipes/isopropyl alcohol to ensure a secure bond.

## STEP 2



Begin by test fitting the covers to the hinge prior to removing the tape backing. The hinge overlays are identified [A] (top) and [B] (bottom), marked on the inner side of each panel. Once hinges are clean and you are comfortable with how the covers fit, peel the film off the double sided tape.



## STEP 3

Press the overlays onto the vehicle, press firmly to ensure they are bonded to the hinge. Once all four are attached, installation is complete.