



DOOR PULL STRAPS

(1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Door Handles

TOOLS REQUIRED

Phillips Screwdriver
T-15 Torx Screwdriver

SKU # J141592

**STEP 1**

Remove (2) T-15 Torx screws from the door handle, and (3) Phillips screws from the bottom of the door panel. Remove the door handle from the vehicle.

**STEP 2**

insert one side of the pull handle in between the door panel and the handle mount. Secure (1) T-15 Torx screw into the original location to secure one side of handle to the door.

Note: Pull the door panel away from the door if necessary for more working room.



STEP 3

Insert the other end of the door pull handle into the door, then reinstall the (1) original T-15 Torx screw. Reinstall (3) Phillips screws into the door panel.



STEP 4

Repeat procedure to opposite side.

Installation is now complete.