



# OLD GLORY DOOR HANDLE INSERTS

(2007-2018 WRANGLER JK)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

#### 4-Door

(2) Left Side Inserts  
(2) Right Side Inserts  
(1) Tailgate Insert  
(10) Screws

#### 2-Door

(1) Left Side Inserts  
(1) Right Side Inserts  
(1) Tailgate Insert  
(6) Screws

### TOOLS REQUIRED

---

Drill  
1/8" Drill Bit  
Phillips Head Screw Driver

## STEP 1



Begin by thoroughly cleaning the door handle surface using soap and water. Allow the door handle time to dry.

## STEP 2



Position the insert into the door handle. Using a 1/8" drill bit, carefully drill a 1/4" deep pilot hole into the factory door handle. Do not drill all the way through the door handle.



## STEP 3

Using a Phillips head screw driver, secure the insert to the door handle using the provided screws. Repeat the process to all remaining doors/tailgate handle.

Installation is now complete.