

## IN-CHANNEL WINDOW DEFLECTORS

(2007-2018 WRANGLER JK - 4 DOOR)

INSTALLATION INSTRUCTIONS

## **CONTENTS**

- (1) LH Front Deflector
- (1) RH Front Deflector
- (1) LH Rear Deflector
- (1) RH Rear Deflector

## **TOOLS REQUIRED**

N/A





STEP 1

Lower the window to the lowest position. Ensure the window channel is clean of any dirt/debris. Insert the rear most portion of the window deflector into the window channel.



STEP 2

Press the front portion of the window deflector into the window channel, ensuring the window deflector is evenly installed. Raise the window to the highest setting to fully seat the window deflector.

Repeat steps 1-2 to the remaining window deflectors. Installation is now complete.