

HD TIRE CARRIER

(1987-1995 WRANGLER YJ) (1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) HD Tire Carrier
- (3) 1/2 x 20 Lug Nuts

TOOLS REQUIRED

1/2" Socket 19mm Socket Ratchet





STEP 1

Remove the spare tire from the vehicle using the appropriate size socket and ratchet.



STEP 2

Remove (5) 1/2" bolts from the spare tire carrier on the tailgate.

Note: Hardware will be reused.





STEP 3

Align the HD tire carrier to the vehicle. Using the (5) original 1/2" bolts, secure the HD tire carrier to the vehicle. Tighten evenly until secure.



STEP 4

Install the spare tire to the vehicle using the (3) included lug nuts. Torque lug nuts to OEM specifications.

Installation is now complete.