



REAR TUBULAR FENDER FLARES

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Rear Fenders
(1) Hardware Kit
(2) Foam Strips

TOOLS REQUIRED

Flat Head Screwdriver
Trim Panel Removal Tool
Metric Socket Set
Drill & Drill Bits

SKU # J164977

STEP 1



Using a flat head screw driver or trim panel removal tool, remove the (5) push clips holding the rear fender liner to the vehicle. Then, firmly pull the stock fender away from the vehicle moving from front to back.

STEP 2



To install the supplied rivnuts, start by enlarging the (8) factory holes circled above using a 23/64" drill bit. Treat any exposed metal with touch up paint or clear nail polish.

STEP 3



Using the supplied handle and long M6 x 1.0, install the rivnuts. Hold the rivnut in place with the handle and tighten the rivnut securing it to the vehicle.

NOTE: RIVNUTS ARE MORE SUSCEPTIBLE TO STRIPPING, DO NOT OVER TIGHTEN THEM.

STEP 4



Install the supplied foam to the fender before installation.

STEP 5



Install the M6 x 1.00 25mm bolts with the supplied flat washer and lock washer on all locations with the installed rivnuts.

STEP 6



Installation is now complete.