



TAILGATE HINGE FLAG & ANTENNA MOUNT

(1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Flag Pole
- (2) Flag Pole Mounts
- (2) Threaded Blocks
- (1) Antenna Mount
- (2) M12x1.75 x 22mm Allen Bolts
- (2) M12 Flat Washers
- (2) M10x1.50 x 40mm Allen Bolts
- (2) 5/16-18 x 1.5" Allen Bolts
- (2) 5/16 Flat Washers
- (6) M3 Allen Bolts

TOOLS REQUIRED

- T-40 Torx Socket
- 2.5mm, 8mm, 10mm Allen Keys
- Ratchet

SKU # J165222
Edited: 02/10/2022

STEP 1

Remove the spare tire from the vehicle. Remove (1) T-40 Torx bolt from each tailgate hinge.

STEP 2

Align (1) threaded block to the tailgate hinge, and secure in place using (1) 5/16 x 1.5" Allen bolt and (1) 5/16 flat washer.

STEP 3

Loosely install the flag pole mount to each threaded block using (1) M12 x 22mm Allen bolt and (1) M12 flat washer per mount. Insert the flag pole, and tighten the flag pole mount hardware.

STEP 4

Secure the antenna mount to the upper flag pole mount using (4) M3 Allen bolts. Tighten until secure.



STEP 5

Use (1) thumb screw to secure a flag to the flag pole.

Installation is now complete.