



TAILGATE MOUNTED FLAG & ANTENNA HOLDER

(2018+ WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Flag Holder
- (2) Flag Holder Mount
- (1) Antenna Mount
- (6) M3 Allen Bolts
- (2) M8 Allen Bolts
- (1) Knob

TOOLS REQUIRED

- T-55 Torx Socket
- 2.5mm, 4mm, 6mm Allen Keys
- Ratchet

STEP 1



Step description here...

STEP 2



Install the (2) flag holder mounts to the tailgate using (1) M8 Allen bolt per mount. Insert the flag holder into the mounts and tighten all of the mounting hardware.

Note: Ensure the (4) threaded holes are facing upwards when installing the flag holder.

STEP 3



Install the antenna mount using (4) M3 Allen bolts, tighten until secure.

STEP 4



Use the (1) knob to secure a flag to the flag holder.

Installation is now complete.