

HOOD PROTECTOR

(2018+ WRANGLER JL) (2020+ GLADIATOR JT)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Hood Protector
- (1) Template
- (7) Threaded Adhesive Mounts
- (7) M8 Allen Bolts

TOOLS REQUIRED

Isopropyl Alcohol Microfiber Cloth 3mm Allen Key





STEP 1

Clean the vehicle hood with isopropyl alcohol and a microfiber cloth, and allow to dry. Lay the template onto the vehicle hood, and adhere the threaded adhesive mounts to the vehicle. Ensure the mounts are facing the correct direction.



STEP 2

Place the hood protector onto the vehicle hood, and secure into place using the (7) Allen head bolts. Tighten until secure.

Installation is now complete.