

REAR CARGO NET / PET DIVIDER

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Storage System

(2) Clips

TOOLS REQUIRED

T-40 Torx Socket





STEP 1

Using the (2) top straps, attach the storage system to the top roll bar on the vehicle. Do not tighten straps.



STEP 2

Using the corner straps, attach the corners to the roll bar on the vehicle. Do not tighten these straps.





STEP 3

Remove (1) T-40 Torx bolt from each side of the vehicle. Place the provided clip onto the bolt, then refasten the bolt into the vehicle.



STEP 4

Clip the side hook straps into the previously fastened clips. Do not tighten these straps.

Jeep

STEP 5



Clip the bottom hook straps into the anchor point on the base of the rear seat.



STEP 6

Tighten all storage system straps evenly.

Installation is now complete.