



---

# 7-PIN TOW PLUG HOUSING SKID PLATE

(2018-2023+ WRANGLER JL)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) Skid Plate
- (2) M10x1.50 x 20mm Bolts
- (2) M10 Lock Washers
- (2) M10 Flat Washers

### TOOLS REQUIRED

---

- 16mm Socket
- Ratchet
- Flathead Screwdriver

**STEP 1**

Fit the trailer wiring housing half way into the skid plate, then route and plug in the trailer wiring harness into the housing. After the housing is plugged in, press the trailer wiring housing into the skid plate.

**STEP 2**

With the trailer wiring secure, bolt the skid plate to the vehicle frame below the bumper using the provided (2) M10x1.50 x 20mm bolts, (2) M10 lock washers, and (2) M10 flat washers. Tighten until secure.

Installation is now complete.