

TONNEAU COVER

(2007-2018 WRANGLER JK - 2 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

TOOLS REQUIRED

N/A



STEP 1



Remove the OEM vehicle top following OEM specified remove steps. Identify the direction of the tonneau cover. The roll bar cutouts fit to the rear-most roll bar on the vehicle.

Note: The tonneau cover is designed to be a tight fit. It is recommended to place the tonneau cover in the sun prior to installation to allow material flexibility.



STEP 2

If the vehicle has a OEM hard top, an additional tailgate bar is required (SKU J179609).

Place the (2) tailgate bar mounting brackets to the vehicle body on each side, and then fit the tailgate bar into the brackets.

Note: The mounting brackets are side specific and are labeled.





STEP 3

Insert the tonneau cover rear rod into the slot in the vehicle tailgate bar.



STEP 4

Drape the tonneau cover over the vehicle cargo area. Form the edges of the tonneau cover around the exterior lip of the vehicle.

Note: Work on each side evenly to allow the material to slowly stretch and aid the installation.





STEP 5

Wrap the roll bar cutouts around the vehicle rear roll bars, use the attached Velcro to secure into place.

Installation is now complete.

This tonneau cover is compatible with the windbreaker (SKU J179610).

pl