



IN-CHANNEL WINDOW DEFLECTORS

(2007-2018 WRANGLER JK - 2 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Front Deflector
(1) RH Front Deflector

TOOLS REQUIRED

N/A

SKU # J183264



STEP 1

Lower the window to the lowest position. Ensure the window channel is clean of any dirt/debris. Insert the rear most portion of the window deflector into the window channel.



STEP 2

Press the front portion of the window deflector into the window channel, ensuring the window deflector is evenly installed. Raise the window to the highest setting to fully seat the window deflector.

Repeat steps 1-2 to the remaining window deflector. Installation is now complete.