



# AGGRESSOR ALUMINUM FENDER FLARES W/ DRL

(2007-2018 WRANGLER JK)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Front Fender Flare
- (1) RH Front Fender Flare
- (1) LH Rear Fender Flare
- (1) RH Rear Fender Flare
- (1) LH DRL Light
- (1) RH DRL Light

#### **FRONT:**

- (2) M8x1.25 x 25mm Allen Bolts
- (14) M8x1.25 x 20mm Allen Bolts
- (34) M8 Flat Washers
- (18) M6 Flange Nuts

#### **Rear:**

- (4) M8x1.25 x 20mm Allen Bolts
- (16) Plastic Push Clips

### TOOLS REQUIRED

---

- Panel Removal Tool
- 10mm Socket/Wrench
- Ratchet
- Wire Strippers/Crimpers
- 5mm Allen Key/Socket

SKU # J189612  
Edited: 08/31/2023

## STEP 1 (FRONT)



Remove (6) 10mm bolts and (2) push clips from the fender liner. Unplug the parking light connector. Firmly pull fender flare away from vehicle.

## STEP 2



Ensure all plastic fender flare clips are removed from the vehicle fender.



## STEP 3

Align the fender flare to the vehicle. Secure the center of the flare to the fender bracket using (1) M8 x 25mm Allen bolt, (2) M8 flat washers, and (1) M8 flange nut.

Secure the fender flare to the vehicle fender lip using (7) M8 x 20mm Allen bolts, (14) M8 flat washers, and (7) M8 flange nuts. Tighten all hardware evenly.



## STEP 4

Secure the DRL light to the fender flare using (2) M6 flange nuts. Adjust the lamp for best fit to the outside of the fender, and tighten the hardware into place.

## STEP 5



Route the fender light wiring towards the vehicle grille turn signal harness. Splice the fender light into the vehicle turn signal/parking lamp circuits using the diagram. After splicing, secure the harness into place away from any moving/hot components.

## STEP 6 (REAR)



Remove (6) plastic push clips from the rear fender. Once removed, firmly pull the fender away from the vehicle body.

## STEP 7



Ensure all plastic fender flare clips are removed from the vehicle fender.

## STEP 8



Align the fender flare to the vehicle. Loosely secure the center of the flare to the top of the wheel arch using (2) M8 x 20mm Allen bolts, (4) M8 flat washers, and (2) M8 flange nuts.

Secure the fender flare to the wheel arch sides using (8) plastic push clips. Once fitted with the push clips, tighten the M8 hardware evenly until fully secure.



---

## STEP 9

Step description here...