

21458 21458B

2013 DODGE
RAM 1500



21458 21458B

2013 DODGE
RAM 1500

2013 DODGE RAM 1500

Billet Grille

Install time: 30 Mins.

TOOLS REQUIRED:

Screwdriver
Flat Screwdriver

PARTS LIST:

(4) Billet Grilles
(8) Centerhole Flange Brackets
(8) U-Nuts
(8) #8 1.5" 6head Screws

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Remove Clips to Remove the Plastic Cover. (Fig. 1)
 - Remove the Grille Shell.
 - Remove the Plastic Grille Support. (Fig. 2)
 - Unclip the Plastic Grille Covers with a Flat Screwdriver. (Fig. 3)
 - Place the Billet Grilles onto the Factory Grille and Place the #8 Screws through the Brackets on the Billet Grille. (Fig. 4)
 - From behind the Grille, Place the U-Nuts onto the Flange Brackets and then Thread them onto the #8 Screws. (Fig. 5)
 - Place back the Plastic Grille Covers (use the Flat Screwdriver to put back the covers).
- Place back the Grille Shell.

INSTALLATION COMPLETE

