

**671458X**  
**54458**  
**51458**  
**2013 DODGE**  
**RAM 1500**



**671458X**  
**54458**  
**51458**  
**2013 DODGE**  
**RAM 1500**

## 2013 DODGE RAM 1500 Mesh Grille

Install time: 45 Mins.

### TOOLS REQUIRED:

Screwdriver  
Flat Screwdriver  
Diegrinder

### PARTS LIST:

(1) Mesh Grille  
(10) L-Brackets  
(10) 6/32 Nylon Lock Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS  
BEFORE ATTEMPTING INSTALLATION.

- Remove Clips to Remove the Plastic Cover. (Fig. 1)
- Remove the Grille Shell.
- Remove the Plastic Grille Support. (Fig. 2)
- Unclip the Plastic Grille Covers with a Flat Screwdriver. (Fig. 3)
- Unclip the Grilles from the Grille Shell and Remove. (Fig. 4)
- With a Diegrinder, Start Cutting the Center and Vertical Bars on the Grille Shell as close to the Outer Grille Shell as possible. (Fig. 5)
- Place the Mesh Grille onto the Grille Shell and Place an L-Bracket and Nylon Lock Nut onto the Threaded Studs. (Fig. 6)

### INSTALLATION COMPLETE

