



WHEEL SPACERS

(2002-2011 RAM)

INSTALLATION INSTRUCTIONS

CONTENTS

- (2) Wheel Spacers
- (1) Red Thread Locker
- (10) Lug Nuts

TOOLS REQUIRED

- Jack
- Jack Stands
- Lug Wrench
- Torque Wrench
- Wire Brush

SKU # R110855/R110856

STEP 1



Raise and support the vehicle using a jack and jack stands. Raise the vehicle so that the tires are just off the ground

STEP 2



Using a lug wrench, remove the wheel.




STEP 3

Using a wire brush, clean any loose rust from the axle hub.



STEP 4

Apply a drop of the supplied thread locker on each wheel stud.



STEP 5

Install the wheel spacer using the supplied lug nuts. Tighten all lug nuts by hand in a star pattern. Then, torque the lug nuts in a star pattern to 130 lb. ft.



STEP 6

Reinstall the original wheel on the new studs. Torque the lug nuts in a star pattern to 130 lb. ft.