



MOLDED MUD GUARDS

(2019+ 1500 - WITHOUT OEM FENDER FLARES)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Mud Guard
- (1) RH Front Mud Guard
- (1) LH Rear Mud Guard
- (1) RH Rear Mud Guard
- (4) Phillips Screws
- (4) Flat Washers
- (2) Screw Clips
- (2) Spring Clips

TOOLS REQUIRED

- Phillips Screwdriver
- 8mm Socket
- Ratchet
- Panel Removal Tool
- Isopropyl Alcohol
- Microfiber Cloth
- Drill (Optional)
- 1/8" Drill Bit (Optional)



**STEP 1
(FRONT)**

Remove (3) 8mm screws from the vehicle. Clean the inner fender liner using isopropyl alcohol.



**STEP 2
(FRONT)**

Peel the double sided tape backing, then install the mud guard to the vehicle using the (3) original 8mm screws. Firmly press the mud guard to the inner fender liner to ensure proper adhesion.

Optional: If necessary, reinforce the mud guards to the vehicle using the included hardware.

**STEP 3
(REAR)**

Remove (3) 8mm screws from the vehicle. Clean the inner fender liner using isopropyl alcohol.

**STEP 4
(REAR)**

Peel the double sided tape backing, then install the mud guard to the vehicle using the (3) original 8mm screws. Firmly press the mud guard to the inner fender liner to ensure proper adhesion.

Optional: If necessary, reinforce the mud guards to the vehicle using the included hardware.

Repeat steps 1-5 to the opposite side of the vehicle. Installation is now complete.