



MUD FLAPS

(2014-2018 CHEVROLET SILVERADO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Pair of Front Mud Flaps
- (1) Pair of Rear Mud Flaps
- (8) Phillips Screws

TOOLS REQUIRED

- Phillips Screwdriver
- T-15 Torx Socket
- Ratchet
- Drill (Optional)
- 1/8" Drill Bit (Optional)

SKU # S123335



**STEP 1
(FRONT)**

Remove (4) T-15 Torx screws in the fender liner. Repeat this procedure to the opposite side.



STEP 2

Align the mud flap to the vehicle. Secure the mud flap using the original (4) T-15 Torx screws. Repeat this procedure to the opposite side.

Front installation is now complete.



STEP 3

Remove (2) T-15 Torx screws from the vehicle.



STEP 4

Align the rear mud flap to the vehicle. Secure the mud flap reusing the original (2) T-15 Torx screws.



**STEP 5
(FRONT AND
REAR)**

Optional Drilling: For additional reinforcement, drill (2) 1/8" holes in the fender and mud flap along the top of the mud guard. Use (2) Phillips screws to secure the top of the mud guard to the fender through the drilled holes.