



MUD FLAPS

(2007-2013 CHEVROLET SILVERADO)

(2007-2013 GMC SIERRA)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Pair of Front Mud Flaps
- (1) Pair of Rear Mud Flaps
- (10) Phillips Screws
- (2) Screw Clips

TOOLS REQUIRED

- Phillips Screwdriver
- 7mm Socket
- Ratchet
- Drill
- 1/8" Drill Bit

SKU # S124058

**STEP 1
(FRONT)**



Remove (2) 7mm screws from the fender liner.

STEP 2



Align the mud flap to the vehicle. Re-install the (2) 7mm screws through the mud flap and back into the vehicle.

**STEP 3**

Using (1) Phillips screw and (1) Screw Clip, secure the lower portion of the mud flap to the vehicle. Insert the screw through the front, ensuring it passes through the fender mount and fender liner. Use the (1) Screw Clip as a nut and tighten the screw. Repeat steps 1-3 to the opposite side.

Front installation is now complete.

**STEP 4
(REAR)**

Using the mud guard as a template, mark the designated areas for drilling with a permanent marker. Drill the designated holes using a 1/8" drill bit.

Repeat this procedure to the opposite.



STEP 5

Secure the mud flap to the vehicle using (4) Phillips screws. Repeat this procedure to the opposite side.

Installation is now complete.