



MOLDED MUD GUARDS

(2007-2013 SILVERADO - WITHOUT OEM FENDER FLARES)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Mud Guard
- (1) LH Rear Mud Guard
- (1) RH Front Mud Guard
- (1) RH Rear Mud Guard
- (16) Phillips Screws
- (16) Flat Washers
- (2) Screw Clips

TOOLS REQUIRED

- Drill & 1/8" Drill Bit
- Panel Removal Tool
- Phillips Screwdriver
- 7mm Socket

STEP 1



Remove (3) screws from the fender liner.

STEP 2



Install (1) threaded clip onto the sheet metal behind the fender liner.

**STEP 3**

Align the mud guard to the vehicle and secure to the vehicle using (3) Phillips screws and (3) flat washers. Optional: Drill and install (1) Phillips screw and (1) flat washer under the mud guard.

**STEP 4
(REAR)**

Using the mud guard as a template, drill (4) holes into the fender lip using a 1/8" drill bit. Once drilled, align the mud guard and secure into place using (4) Phillips screws and (4) flat washers.

Repeat steps 1-4 to the opposite side of the vehicle. Installation is now complete.