



MOLDED MUD GUARDS

(2014-2018 SILVERADO - WITHOUT OEM FENDER FLARES)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Mud Guard
- (1) RH Front Mud Guard
- (1) LH Rear Mud Guard
- (1) RH Rear Mud Guard
- (2) Phillips Screws
- (2) Flat Washers

TOOLS REQUIRED

- Phillips Screwdriver
- T-15 Torx Screwdriver/Bit



**STEP 1
(FRONT)**

Remove (4) T-15 Torx screws from the fender liner.



STEP 2

Align the mud guard to the vehicle fender, and secure into place using the original (4) T-15 Torx screws.

**STEP 3
(REAR)**

Clean the fender lip using isopropyl alcohol and a microfiber cloth. Remove the (2) original T-15 Torx screws. Peel the red tape backing, and align the mud guard to the vehicle. Secure the mud guard using the (2) original T-15 Torx screws. Use the included (1) Phillips screw and (1) flat washer as reinforcement along the upper edge if necessary.

**STEP 4**

Repeat steps 1-3 to the opposite side of the vehicle.

Installation is now complete.