



# MOLDED MUD GUARDS

(2017-2020 F-250 & F-350 - WITHOUT OEM FENDER FLARES)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Front Mud Guard
- (1) LH Rear Mud Guard
- (1) RH Front Mud Guard
- (1) RH Rear Mud Guard
- (10) Phillips Screws
- (10) Flat Washers
- (8) Screw Clips
- (4) Spring Clips

### TOOLS REQUIRED

---

- 7/32" Socket
- Ratchet
- Phillips Screwdriver
- Panel Removal Tool
- Exterior Detailer
- Microfiber Cloth
- Drill & 1/8" Drill Bit

**STEP 1  
(FRONT)**

Remove (2) screws from the front plastic panel.

**STEP 2**

Secure the mud guard to the vehicle using the (2) original screws. Install (1) spring clip to the upper edge of the mud guard. Optional: Drill (1) hole in the fender liner using the mud guard as a template. Secure the mud guard to the liner using (1) Phillips screw and (1) screw clip.

**STEP 3  
(REAR)**

Remove (2) push clips from the rear plastic panel.

**STEP 4**

Insert (2) screw clips in place of the original plastic push clips. Align the mud guard to the vehicle, and secure using (2) Phillips screws and (2) flat washers. Use (1) spring clip at the top of the mud guard.

Repeat steps 1-4 to the opposite side of the vehicle. Installation is now complete.