



MUD GUARDS

(2015-2020 F-150 W/O FENDER FLARES)

INSTALLATION INSTRUCTIONS

CONTENTS

- (2) Front Mud Guards
- (2) Rear Mud Guards
- (8) Phillips Screws
- (8) Flat Washers
- (6) U-Clips
- (4) Spring Clips

TOOLS REQUIRED

- Stubby Phillips Screwdriver
- 5.5mm Socket
- Socket Wrench
- Panel Removal Tool

SKU # T546992

**STEP 1
(FRONT)**



Clean the designated area on the fender with exterior detailer/isopropyl alcohol. Remove the (2) 5.5mm bolts on the fender.

STEP 2



Peel back the film on the double sided tape on the mud guard. Align the mud guard to the vehicle, and install the (2) 5.5mm bolts back into the vehicle while aligning the double sided tape to the vehicle.

**STEP 3**

Install the (1) spring clip at the top of the mud guard to hold the mud guard to the fender. Installation is now complete.

**STEP 4
(REAR)**

Clean the designated area using exterior detailer/isopropyl alcohol. Using a panel removal tool, remove the (2) push clips along the bottom of the fender.

**STEP 5**

Using (2) U-Clips, attach the clips to the fender on the vehicle. Peel back the film on the double sided tape from the mud guard. Using (2) Phillips screws and (2) flat washers, attach the mud guard to the vehicle. Make sure to align the top of the guard to the body of the vehicle.

**STEP 6**

Install the (1) spring clip at the top of the mud guard to hold the mud guard to the fender. Installation is now complete.