



MUD FLAPS

(2004-2014 F-150; WITH OEM FENDER FLARES)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Front Pair of Mud Flaps
- (1) Rear Pair of Mud Flaps
- (8) Phillips Screws
- (8) Screw Clips
- (4) Push Clips
- (2) M6 x 35mm Bolts
- (2) M6 Flat Washers

TOOLS REQUIRED

- Phillips Screwdriver
- 10mm Socket
- Panel Removal Tool
- Drill
- 5/32" Drill Bit
- Paint/Permanent Marker

SKU # T554365

**STEP 1
(FRONT)**

Remove (1) plastic push clip from the bottom portion of the fender flare. Using (1) provided push clip, temporarily install the mud flap to the fender flare. Using a permanent marker, mark the fender flare for drilling using the mud flap as a template.

**STEP 2**

Remove mud flap before drilling. Drill the previously marked holes using a 5/32" drill bit. Once drilled, use the provided (2) Phillips screws and (2) screw clips to secure the mud guard to the vehicle.

Install the (1) provided plastic push clip into the bottom of the mud flap through to the fender. Repeat steps 1-2 to the opposite side.

**STEP 3
(REAR)**

Remove (1) 10mm bolt from the bottom of the bed side, and (1) plastic push clip from the inside of the fender flare.

STEP 4

Using (1) provided push clip, temporarily install the mud flap to the fender flare. Using a permanent marker, mark the fender flare for drilling using the mud flap as a template.

**STEP 5**

Remove mud flap before drilling. Drill the previously marked holes using a 5/32" drill bit. Once drilled, use the provided (1) Phillips screws and (1) screw clips to secure the mud guard to the vehicle. Install (1) provided plastic push clip in the original location through the mud flap into the fender flare.

**STEP 6**

Install (1) provided M6 x 35mm bolt and (1) M6 flat washer into the lower portion of the bed side to secure the mud flap to the vehicle. Repeat steps 3-6 to the opposite side. Additional hardware can be used for optional mud flap reinforcement.

Installation is now complete.