



MOLDED MUD GUARDS

(2015-2020 F-150 - WITHOUT OEM FENDER FLARES)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Mud Guard
- (1) RH Front Mud Guard
- (1) LH Rear Mud Guard
- (1) RH Rear Mud Guard
- (8) Phillips Screws
- (8) Flat Washers
- (6) Screw Clips
- (4) Spring Clips

TOOLS REQUIRED

- 5.5mm Socket
- Ratchet
- Phillips Screwdriver
- Panel Removal Tool



**STEP 1
(FRONT)**

Remove (2) 5.5mm screws from the fender lip panel.



STEP 2

Align the mud guard to the vehicle, and secure the mud guard to the vehicle (2) Phillips screws and (2) flat washers.

STEP 3



Install (1) spring clip on the upper portion of the mud guard, ensuring the clip attaches to the mud guard and the vehicle fender metal.

Front installation is now complete.

**STEP 4
(REAR)**



Remove (2) plastic push clips from the fender lip panel.

STEP 5

Place (2) screw clips onto the fender lip behind the plastic panel where the previous plastic push clips were placed.

STEP 6

Secure the mud guard using (2) Phillips screws and (2) flat washers. Secure the upper portion of the mud guard using (1) spring clip, ensuring the clip attaches to the mud guard and the vehicle fender metal.

Repeat steps 1-6 to the opposite side of the vehicle. Installation is now complete.