



# MOLDED MUD GUARDS

(2015-2020 F-150 - WITHOUT OEM FENDER FLARES)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Front Mud Guard
- (1) RH Front Mud Guard
- (1) LH Rear Mud Guard
- (1) RH Rear Mud Guard
- (1) LH Bed Bracket
- (1) RH Bed Bracket
- (4) Plastic Push Clips
- (8) Phillips Screws
- (4) Screw Clips
- (4) M6 Bolts w/ Retainers
- (12) M6 Flat Washers
- (6) Spring Clips

### TOOLS REQUIRED

---

- Phillips Screwdriver
- Panel Removal Tool
- Drill (Optional)
- 1/8" Drill Bit (Optional)

SKU # T576601



## STEP 1 (FRONT)

Remove (2) 7mm bolts from the inner fender liner. Align the mud guard, and re-install the (2) 7mm bolts. Fold the upper tab under the fender lip.



## STEP 2

Secure the upper portion of the mud guard using (1) spring clamp.



## STEP 3 (REAR)

Remove the (2) push clips from the bottom of the bed. Align the mud guard, and hold into place using (2) Phillips screws and (2) screw clips. Fold the upper tab under the fender lip. Secure the top of the mud guard using (2) spring clips.



## STEP 4

Secure the rear of the mud guard using (1) bed bracket, (1) M6 bolt , flat washer, & retainer on each side of the bracket.



---

## STEP 5

Secure the bottom of the mud guard using (1) M6 bolt and (1) flat washer.

Repeat steps 1-5 to the opposite side of the vehicle. Installation is now complete.