## REDROCK

## CENTER CONSOLE ARM REST COVER

(2016-2023 TACOMA)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Center Console Arm Rest Cover **TOOLS REQUIRED** 

N/A



STEP 1

Align the center console arm rest cover to the center console arm rest. Ensure the rounded portion of the cover is towards the front. Begin stretching the (2) elastic bands around the arm rest lid.



STEP 2

Position the arm rest cover evenly across the lid. Ensure the elastic bands are not twisted. Close the center console lid and adjust fitment as necessary.

Installation is now complete.