



BED TIE DOWN SET

(2005-2021 TACOMA)

INSTALLATION INSTRUCTIONS

CONTENTS

(4) Bed Tie Down Mounts

TOOLS REQUIRED

T-40 Torx Socket
Ratchet

STEP 1



Remove (1) T-40 Torx bolt from the bed. Remove OEM bed mount from the vehicle.

STEP 2



Remove the OEM lock, flat, and star washer from bolt, then remove the bolt from the OEM bed mount. Install the OEM hardware onto the new bed tie down mount in the same order as OEM.



STEP 3

Secure the new bed tie down mount to the vehicle. Repeat steps 1-3 to the remaining bed mounts.

Installation is now complete.