



LOW PROFILE WINDOW DEFLECTORS

(2016-2022 TACOMA - DOUBLE CAB)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Window Deflector
- (1) RH Front Window Deflector
- (1) LH Rear Window Deflector
- (1) RH Rear Window Deflector

TOOLS REQUIRED

- Isopropyl Alcohol
- Microfiber Cloth



STEP 1

Roll the window downwards. Using isopropyl alcohol and a microfiber cloth, clean the inside of the weatherseal where the window rests. Allow the weatherseal to fully dry.



STEP 2

Fit the window deflector into the window channel prior to tape backing removal. Once familiar with fitment, peel the red tape backing from the double sided tape.

Note: Fit the rear section of the visor into the window channel first (towards the rear of the vehicle), then route the front section into the channel last (towards the vehicle mirror).

STEP 3



Place the window deflector into the window channel. Ensure the channel is at the highest point in the channel. Roll the vehicle window upwards to fully adhere the double sided tape.

STEP 4



Repeat steps 1-3 for the remaining window deflectors.

Installation is now complete.