



BED POWER SUPPLY LOCK BOX

(2016-2022+ TACOMA)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Lock Box
- (2) Keys
- (6) M6 Allen Bolts
- (6) M6 Flat Washers

TOOLS REQUIRED

- T-30 Torx Socket/Key
- 4mm Allen Socket/Key
- Ratchet



STEP 1

Remove the (6) T-30 Torx bolts from the outer edge of the power supply.



STEP 2

Align the lock box to the power supply container, and secure into place using (6) M6 Allen bolts and (6) M6 flat washers. Tighten until secure.