

30-32" SPARE TIRE COVER

(UNIVERSAL FITMENT)

-1	INICTAL	I ATION	INICTDI	JCTIONS
	INDIAL	LAILUM	11/1/2/1/2/1	11 11 11 11 13

CONTENTS

(1) Spare Tire Cover

TOOLS REQUIRED

Wheel Cleaner Microfiber Cloth





STEP 1

Clean the wheel with automotive wheel cleaner. Drape the spare tire cover over the top of the spare tire. Tuck the top of the cover around the back of the tire.



STEP 2

Pull the spare tire cover down around the tire. Be sure to keep the center of the tire cover near the middle of the wheel to have enough slack for the bottom of the tire.





STEP 3

Pull the cover around the bottom of the tire.



Adjust the cover to the spare tire if necessary.

Installation is now complete.