



# FRONT ADJUSTABLE TRACK BAR FOR 0-6” LIFT

(2007-2018 WRANGLER JK)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Front Adjustable Track Bar

### TOOLS REQUIRED

---

21mm Socket  
21mm Wrench  
Ratchet  
Breaker Bar  
Adjustable Wrench  
Tape Measure


SKU # J150571

## STEP 1



Park the vehicle with the steering wheel straight. Measure the distance from the upper shock absorber mount to the outer edge of the fender flare on each side of the vehicle to determine the center-point of the vehicle.

## STEP 2



Locate the track bar under the vehicle. Remove the (1) 21mm bolt and nut from the vehicle frame.

Note: Hardware will be reused during assembly.



## STEP 3

Remove (1) 21mm bolt and flag nut from the vehicle axle mount. Remove the original track bar from the vehicle.

Note: Hardware will be reused during assembly.



## STEP 4

Adjust the track bar length similar to the original track bar. Do not tighten the jam nut.



## STEP 5

Fit the track bar to the vehicle frame using the original (1) 21mm bolt and nut. Do not fully tighten the hardware.



## STEP 6

Fit the track bar into the vehicle axle mount using the original (1) 21mm bolt and flag nut.

Note: Prying on the axle/turning the steering wheel slightly may be necessary to aid alignment. If the vehicle has lifted suspension, re-measure the center-point of the vehicle, and adjust the track bar to fit into the axle mount.



---

## STEP 7

Tighten the jam nut to secure the adjustment. With the vehicle on the ground, torque all of the track bar bolts to 125 ft. lbs.

Installation is now complete.